


SUNVISION PRO 28LX HOOD



LL = LEFT LAMPHOLDER
 B = BALLAST
 F = FAN
 R = RELAY (CONTACTOR)
 TB = TERMINAL BLOCK

RL = RIGHT LAMPHOLDER
 C = CAPACITOR
 P = POWER
 T = TIMER

FRONT OF BED




6220 CHURCHMAN BYPASS
 INDIANAPOLIS, IN 46203

21484 REV. B

NOTE:

1. WIRE COLORS MAY NOT BE EXACTLY AS SHOWN

SUNVISION PRO 28LX HOOD




LL = LEFT LAMPHOLDER
 B = BALLAST
 F = FAN
 R = RELAY (CONTACTOR)
 TB = TERMINAL BLOCK

RL = RIGHT LAMPHOLDER
 C = CAPACITOR
 P = POWER
 T = TIMER

WARNING: ALTERING THE DESIGN, TIMER SYSTEM, OR WIRING FROM THAT SHOWN HEREIN, WILL VOID THE WARRANTY, AND MAY RESULT IN A VIOLATION OF FEDERAL LAW.

SUNVISION PRO 28LX BENCH



LL = LEFT LAMPHOLDER
 B = BALLAST
 F = FAN
 HC = HOUR COUNTER

RL = RIGHT LAMPHOLDER
 C = CAPACITOR
 P = POWER JACK

FRONT OF BED




6220 CHURCHMAN BYPASS
 INDIANAPOLIS, IN 46203

21485 REV. B

NOTE:

1. WIRE COLORS MAY NOT BE EXACTLY AS SHOWN

SUNVISION PRO 28LX BENCH



WARNING: ALTERING THE DESIGN, TIMER SYSTEM, OR WIRING FROM THAT SHOWN HEREIN, WILL VOID THE WARRANTY, AND MAY RESULT IN A VIOLATION OF FEDERAL LAW.

- | | |
|----------------------|-----------------------|
| LL = LEFT LAMPHOLDER | RL = RIGHT LAMPHOLDER |
| B = BALLAST | C = CAPACITOR |
| F = FAN | P = POWER JACK |
| HC = HOUR COUNTER | |