


SUNVISION PRO 24ST CANOPY



LL = LEFT LAMPHOLDER
 B = BALLAST
 F = FAN
 R = RELAY (CONTACTOR)
 TB = TERMINAL BLOCK
 S = SWITCH
 f = FUSE

RL = RIGHT LAMPHOLDER
 C = CAPACITOR
 P = POWER
 T = TIMER
 FB = FACE TANNER BALLAST
 TLL = TURBL LEFT LAMPHOLDER
 TRL = TURBO RIGHT LAMPHOLDER

FRONT OF BED




6220 CHURCHMAN BYPASS
 INDIANAPOLIS, IN 46203

22222 REV. A

SUNVISION PRO 24ST CANOPY

NOTE:
1. WIRE COLORS MAY NOT BE EXACTLY AS SHOWN.




LL = LEFT LAMPHOLDER
B = BALLAST
F = FAN
R = RELAY (CONTACTOR)
TB = TERMINAL BLOCK
S = SWITCH
f = FUSE

RL = RIGHT LAMPHOLDER
C = CAPACITOR
P = POWER
T = TIMER
FB = FACE TANNER BALLAST
TLL = TURBL LEFT LAMPHOLDER
TRL = TURBO RIGHT LAMPHOLDER

WARNING : ALTERING THE DESIGN, TIMER SYSTEM, OR WIRING FROM THAT SHOWN HEREIN, WILL VOID THE WARRANTY, AND MAY RESULT IN A VIOLATION OF FEDERAL LAW.

SUNVISION PRO 24S BENCH



LL = LEFT LAMPHOLDER
 B = BALLAST
 F = FAN
 HC = HOUR COUNTER

RL = RIGHT LAMPHOLDER
 C = CAPACITOR
 P = POWER




6220 CHURCHMAN BYPASS
 INDIANAPOLIS, IN 46203

22224 REV. A

SUNVISION PRO 24S BENCH

NOTE:
1. WIRE COLORS MAY NOT BE EXACTLY AS SHOWN.



LL = LEFT LAMPHOLDER
B = BALLAST
F = FAN
HC = HOUR COUNTER

RL = RIGHT LAMPHOLDER
C = CAPACITOR
P = POWER JACK

WARNING : ALTERING THE DESIGN, TIMER SYSTEM, OR WIRING FROM THAT SHOWN HEREIN, WILL VOID THE WARRANTY, AND MAY RESULT IN A VIOLATION OF FEDERAL LAW.